aiwa

Adventure Mini IP67 | SB-X80

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

User Manual
使用者指南
使い手説明書
उपभोक्तागाइड
사용자 설명서
คู่มือการใช้
hướng dẫn sử dụng
प्रयोगकर्ता पुस्तिका

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Important Safety Instructions

1. Please do not install device near any form of heat sources.
2. Please use accessories specified by the manufacturer.
3. Please refer all servicing to qualified personnel should there be any form of damage to the device.
4. Keep this user manual for future reference/ troubleshooting.
5. Please heed ALL safety cautions.

## SAFETY CAUTIONS

1. Keep device AWAY from fire and heat sources at all times.
2. Do NOT attempt to disassemble or alter the device.
3. Do NOT expose the device to excessive heat. (Direct sunlight e.g.).
4. Product label is located at the bottom of the product.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Unboxing

SB-X80

Micro USB
charging cable

AUX Cable

Please refrain from using any damaged components.
Contact your local authorised aiwa distributor/customer service

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Overview

1. Power button
2. Play/ Pause/ TWS Connection/ Disconnection
3. Volume -/ Previous song (Short press)
4. Volume +/ Next song (Short press)
5. Microphone
6. Charging indicator
7. Micro USB charging port
8. Reset button
9. AUX - In Port

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Walkthrough - Power ON / OFF




Hold power button ⑤ for 3 seconds.
(Refer to device overview page)

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Walkthrough - Connection

1. Power on SB-X80.
2. Find "SB-X80" in your mobile devices list and connect.
3. Long press play/pause button (Refer to device overview page) to terminate connection.

*Make sure there's only one device connecting at the same time*
*Make sure devices are within working distance (within 10 metres)*
*Use mode button to interchange playback mode (as in this order)*

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Walkthrough - AUX Connection



1. Power on SB-X80.
2. Connect 3.5mm AUX cable.

*Use mode button to interchange playback mode (as in this order).*

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Walkthrough - Answering Calls




**Short press -** Play/Pause button to answer an incoming call.
**Long press -** Play/Pause button calls button to reject an incoming call.
**Short press -** Play/Pause button calls button to end an ongoing call.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Walkthrough - True Wireless Stereo



Double press play button on both devices simultaneously to establishment TWS connection.

After successful connection,

*Device unit with flashing LED - Host unit*
*Device with stable LED - Secondary right channel*

Perform connection (refer to Device Walkthrough - Connection) with Host unit.

Long press play button to terminate TWS connection.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device Walkthrough - Battery & Charging



Connect Micro-USB charging cable to any power source and to SB-X80 as shown.

Charging time - Approx. **3 Hours**
Playback time - Approx. **10 Hours**

*Low battery indicator - "Beep" sound every 15 seconds X 3 before device automatic shutdown*

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Cleaning & maintenance

Wipe down SB-X80 with a soft dry cloth.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Troubleshooting

***I can't find "SB-X80" on my device's list/ unstable connection.***

1. Make sure "SB-X80" and your device are within working distance.
2. Make sure SB-X80 is charged and has enough power.
3. Re-attempt to pair again.

***Disconnection occured within working distance.***

1. Please make sure there are no metals or other materials within a relatively close range which will interfere with the connection.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Customer service

For more product information please visit www.int-aiwa.com.

Contact your local authorised dealer/ customer service. Refer to the warranty label provided in the box.

## Limited Warranty

Please refer to the warranty label provided in the box.

Note: Disassembling device voids warranty.

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

## Device specifications

Model - SB-X80

Rated power - 5W

Technology - V5.0

Bluetooth Profile - A2DP, HFP, HSP, AVRCP

Frequency response - 20Hz - 20KHz

THD - ≤1%

Connection Range - 20M

Battery Capacity - 1800mAh

Speaker Dimension - 85 x 85 x 46 mm

Weight - 215g

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com © All Rights Reserved

aiwa

Aiwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com