

進口商/委製商:勁永國際股份有限公司 地址:23675新北市土城區中央路四段49號 Tel:+886-2-2269-9889 www.pqigroup.com



DQ1 PD05 Power Bank

Power Quotient International Co., Ltd. Address : No.49, Sec. 4, Zhongyang Rd, Tucheng Dist., New Taipei City 23675, Taiwan Tel : +886–2–2269–9889 www.pajgroup.com

POCKET PORTABLE POWER BANK

INSTRUCTION MANUAL

Thank you for purchasing P91[•] PD05 Power Bank!

口袋型隨身行動電源說明書

感謝您購買 ₽91[●] PD05 行動電源!

在使用您的新設備之前,請仔細閱讀本說明手冊 這樣您就可以安全地使用您的新設備並充分享受其所有功能。 請務必將本說明手冊保存在安全的地方以備日後參考。

產品介紹



LED顯示屏

按下唤醒按鈕後,LED顯示屏即可顯示目前的電量。

如何為行動電源充電

- 使用變壓器和充電線為裝置充電
- •裝置充電時,上面的液晶數位螢幕會顯示電量。 當顯示為100時,即代表裝已完全充電。
- 在本裝置進行充電時,請勿使用本裝置為其他裝置充電。
- 充電時請使用正確的輸入電流(請參閱產品規格),以確保裝置的使用壽命。

如何使用本裝置

只要插入內置的USB C介面, 就可以為你的設備充電,如右圖所示



安全使用準則

使用本裝置前,請先閱讀說明手冊。

• 使用前請將裝置充電完全。

- 在任何情況下,請勿在高於許可溫度範團内的環境下或在裝置潮濕時使用。
- 請避免將裝置直接曝曬於陽光下。請遠離火源和熱源。
- •請勿將裝置泡入水中或放入火源中。
- •請勿撞擊、丢擲或試圖打開裝置。
- •請放在嬰兒或孩童無法接觸的地方。
- •請勿允許孩童在没有成人監督的情況下使用裝置。
- 為裝置充電時,請使用適合的變壓器。
- •請注意,電池不能反充電。
- 長時間未使用可能會造成電池品質降低請至少每3個月讓電池完全充電和放電。
- 長期不使用時,請將裝置存放在乾燥的環境。
- 報廢裝置時,請確定妥善丢棄在電池回收站請勿丢棄於垃圾中。
- 不支持同時充放電功能。

產品規格

- 刑 號:PD05
- 產品名稱:口袋型隨身行動電源
- 入 (Type-C/Type-C Connector) : 5V-2.0A/9V-2.0A 輸
- 出 (Type-C Connector): 5V-3.0A/9V-2.2A/12V-1.5A
- 電池類型:可充式鋰電池 | 電池容量:18.25Wh 額定容量:5V--2950mAh/9V--1550mAh/12V--1200mAh
- 操作溫度:0℃-35℃ | 外殼材質:PC/ABS 寸: 78.8mm x 36.2mm x 26.9mm R
- 量:102g ± 1g | 保固:1 年 | 產地:中國 重

包裝內含物

- Please fully charge the device before initial use.
 Do not under any circumstances use the device in an environment hotter than the allowable temperature range.
 Do not under any circumstances use the device when its wet, or under water.
 Please void placing the device in direct sunlight.
 Keep away from fire, or extreme heat.
 Please do not submerge the device in water or place the device in fire.
 Please do not strike, throw, or attempt to open the device.
 Keep out of the reach of infants and children.
 Please do not strike, throw, or attempt to open the device.
 Keep out of the reach of infants and children.
 Please use an appropriate cable and adapter when charging the device.
 Note that the battery should not be reverse-charged.
 Extended periods without use can cause the battery to degrade. Please allow the battery to fully charge and discharge at least once every 3 months.
 Store the device in a dry environment when not in use for extended periods of time.
 When disposing of the device, please make sure to do so properly at a battery recycling station.
 Do not dispose the batter pack in the trash.
 Does not support the function of charging and discharging at the same time.

Product Specifications

Model name : PD05 Product Name : Pocket portable power bank Input1 (Type-C/Type-C Connector) : 5V=2.0A/9V=2.0A Output (Type-C Connector) : 5V=3.0A/9V=2.2A/12V=1.5A Battery Type : Rechargeable Li-Power Bank | Cell Capacity : 18.25Wh Nominal Voltage : 2950mAh/5V \ 1550mAh/9V \ 1200mAh/12V Shell Material : PC/ABS

Package Contents

行動電源 x 1、說明書x 1、USB A to C充電線x 1

Power Bank x $1 \cdot$ User Manual x $1 \cdot$ USB A to C Cable x 1

so that you can use your new device safely and fully enjoy all of its features. Be sure to keep this instruction manual in a safe place for future reference. Product Introduction USB C Input/Output: PD/QC 3.0 Connector cover

Before using your new device.Please carefully read this instruction manual



LED Indicator Light

After pressing the wake up button, the LED display can display the current power.

How to charge the Power Bank

- Charge the device with a compatible cable and charger.
- While the device is charging, the LED digital display above will display the power level. When it shows 100, it means the device is fully charged.
- Please do not charge turn on the battery pack, or use the battery pack to
- charge other devices, when the battery pack is charging.
- Please use an appropriate input current (see product specifications), when charging to ensure the service lifetimne of the device.

How to charge devices using the Power Bank

Just plug in the built-in USB C connector to charge your device, as shown on the right.



