

Product Manual: Rotating Glass Ornament Decor (Set of 2)

ITM. / ART.: 1851683 | **Use:** Indoor Decorative Use Only

IMPORTANT, RETAIN FOR FUTURE REFERENCE:READ CAREFULLY

Customer Support

If you have questions, missing parts, or broken parts, please contact Alice Yang

- **Email:** alice@kindhk.com

Quick Start Guide

1. Battery Installation / Replacement Instructions:

- 6 AA batteries required (included).
- Locate the battery compartment on the bottom .
- Remove the battery compartment door .
- Insert the **3 new AA batteries** per ball.
 - *Important:* Ensure batteries are installed with the correct polarity (+ and -) .
- Close the battery compartment door .

2. Operating the Lights and Rotating function.

The switch is located on the bottom of the base.

Switch Position	Mode	Function Detail
I	ON	Warm white lights on and the ball rotating.
O	OFF	Turn the lights off and the ball stop rotating.
	TIMER	Warm white lights on and the ball rotating. Timer: 6 hours on, 18 hours off.

> **Note:** When using the timer , the light and rotating will turn back on automatically at the same time the next day .

Battery Replacement

Required: 3 AA 1.5V Alkaline batteries per ball.

1. Locate the battery compartment on the bottom of the ball.
2. Remove the battery compartment door .
3. Insert **3 new AA batteries** .
 - *Important:* Ensure batteries are installed with the correct polarity (+ and -) .
4. Close the battery compartment door .

Safety & Care Warnings

- **This is Not a Toy:** Keep out of reach of children .
- **Storage:** Remove batteries during periods of non-use to prevent corrosion .
- **Heat Safety:** Keep batteries away from combustible materials, fire, or extreme heat .

Disposal of Used Batteries

- All persons have a responsibility to properly dispose of batteries.
- Be sure to separate batteries from household garbage. Never place batteries in any curbside collection carts because they can overheat, explode, and cause fires.
- Batteries can be dropped off at designated battery disposal facilities. Please search online for local collection sites.
- Batteries can be dangerous if mishandled. Handle batteries with care. Keep out of reach of children. Keep batteries away from combustible materials. Avoid storing batteries at extreme temperatures. Do not dispose of it in fire or heat. Do not puncture, damage, or disassemble. Do not mix old batteries and new batteries.
- This battery contains toxic materials whose injection into ecosystems may cause harm. When added to land fills, the toxic materials may enter the local groundwater system and propagate through the food chain in various ways, causing damage to the environment.

BATTERY WARNINGS

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment that is not to be used for an extended period of time.
- Remove used batteries promptly.

Always replace the whole set of batteries at one time, taking care not to mix old and new ones or batteries of different types. When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.
- For recycling and disposal of batteries to protect the environment, please check the Internet or your local phone directory for local recycling centers and / or follow local government regulations.

LED旋轉玻璃球聖誕擺飾2件組產品手冊

商品編號：1851683 | 用途：僅限室內裝飾使用

重要提示：請妥善留存，以備日後查閱，敬請仔細閱讀

客戶支援

若您有任何疑問、發現配件缺失或破損，請聯繫 Alice Yang

- 電子郵箱：alice@kindhk.com

快速入門指南

1. 電池安裝 / 更換說明

- 本產品需要6顆 AA 電池（已包含）。
- 找到底部的電池倉位置。
- 打開電池倉蓋。
- 每個擺飾各裝入3顆全新的3號（AA）電池。
 - **重要提示：請確保電池正負極（+/-）安裝正確。**
- 合上電池倉蓋。

2. 燈光及旋轉功能操作。

開關位於底座底部，功能說明如下：

開關檔位	模式	功能詳情
I	開啟	暖白燈亮起，擺件旋轉。
O	關閉	燈光熄滅，擺件停止旋轉。
	定時	暖白燈亮起，擺件旋轉；定時模式：亮 6 小時，熄 18 小時。

> 註：使用定時功能時，燈光和旋轉功能會在次日同一時間自動開啟。

電池更換

每款擺件需配備3顆1.5V 鹼性 3 號 (AA) 電池，更換步驟：

1. 找到擺件底部的電池倉。
2. 打開電池倉蓋。
3. 每個擺飾各裝入3顆新的3號 (AA) 電池。
 - 重要提示：請確保電池正負極 (+/ -) 安裝正確。
4. 合上電池倉蓋。

安全與保養警示

- 非玩具：請置於兒童接觸不到的地方。
- 存放說明：長期不使用時，請取出電池，防止電池滲液腐蝕。
- 防燙安全：請將電池遠離易燃物、明火及高溫環境。

廢舊電池處理

- 所有使用者均有責任妥善處理廢舊電池。
- 請將電池與生活垃圾分類存放，切勿將電池投入路邊垃圾桶，電池可能因過熱發生 爆炸並引發火災。
- 可將廢舊電池送至指定回收點，請透過網路查詢當地回收站點。
- 電池處理不當存在安全隱患，請注意輕拿輕放，置於兒童接觸不到的地方；遠離易 燃物，避免在極端溫度下存放；切勿投入火中或靠近高溫處，切勿刺穿、損壞或拆解電 池，切勿新舊電池混合使用。
- 本電池含有毒物質，若進入生態系統會造成危害；若隨垃圾填埋，有毒物質可能滲 入當地地下水系統，並透過多種途徑進入食物鏈，對環境造成破壞。

電池使用警示

- 請始終購買與預期用途匹配、規格和型號均合適的電池。
- 更換電池時，請將整組電池一同更換。
- 安裝電池前，請清潔電池電極及設備接觸點。
- 請確保電池正負極 (+/ -) 安裝正確。
- 設備長期不使用時，請取出內部電池。
- 及時取出廢舊電池。

更換電池時務必整組更換，切勿將新舊電池、不同類型電池混合使用。若將不同品牌、不同類型電池混用，或新舊電池混用，部分電池會因電壓、容量差異發生過放電，可能導致電池滲液、鼓包甚至破裂，進而造成人身傷害。

- 為保護環境，回收及處理電池時，請透過網路或本地電話簿查詢當地回收中心，或遵循當地政府相關規定。此類電池環保署文件編號：EPH2417389AR39

DISTRIBUTED BY:
COSTCO WHOLESALE CORPORATION
P.O. BOX 34535
SEATTLE, WA 98124-1535
USA
1-800-774-2678
WWW.COSTCO.COM

COSTCO WHOLESALE CANADA LTD.*
415 W. HUNT CLUB ROAD
OTTAWA, ONTARIO
K2E 1C5, CANADA
1-800-463-3783
WWW.COSTCO.CA
* FAISANT AFFAIREAU QUÉBEC SOUS
LE NOM LES ENTREPÔTS COSTCO

IMPORTADO POR:
IMPORTADORA PRIMEX S.A. DE C.V.
BLVD. MAGNOCENTRO NO. 4
SAN FERNANDO LA HERRADURA
HUIXQUILUCAN, ESTADO DE MÉXICO
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
WWW.COSTCO.COM.MX

COSTCO WHOLESALE UK LTD /
COSTCO ONLINE UK LTD
HARTSPRING LANE
WATFORD, HERTS
WD25 8JS
UNITED KINGDOM
01923 213113
WWW.COSTCO.CO.UK/CONTACT

COSTCO WHOLESALE SPAIN S.L.U.
POLÍGONO EMPRESARIAL LOS GAVILANES
C/ AGUSTÍN DE BETANCOURT, 17
28906 GETAFE (MADRID) ESPAÑA
NIF: B86509460
900 111 155
WWW.COSTCO.ES/CONTACT

COSTCO FRANCE
1 AVENUE DE BRÉHAT
91140 VILLEBON-SUR-YVETTE
FRANCE
01 80 45 01 10
WWW.COSTCO.FR/CONTACT

COSTCO WHOLESALE ICELAND EHF.
KAUPTÚN 3-7, 210 GARDABAER
ICELAND
WWW.COSTCO.IS/CONTACT

COSTCO WHOLESALE AUSTRALIA PTY LTD
17-21 PARRAMATTA ROAD
LIDCOMBE NSW 2141
AUSTRALIA
WWW.COSTCO.COM.AU

COSTCO WHOLESALE KOREA, LTD.
40, ILJIK-RO
GWANGMYEONG-SI
GYEONGGI-DO, 14347, KOREA
1899-9900
WWW.COSTCO.CO.KR


COSTCO WHOLESALE JAPAN LTD.
2 KAKUCHI, 2 GAIKU, KANEDA-NISHI
361 URIKURA, KISARAZU SHI
CHIBA, 292-0007 JAPAN
0570-200-800 • WWW.COSTCO.CO.JP

COSTCO (CHINA) INVESTMENT CO., LTD.
ROOM 01 MEZZANINE
NO. 5178, KANG XIN HIGHWAY
PUDONG NEW DISTRICT
SHANGHAI
CHINA 201315
+86-21-6257-7065

COSTCO WHOLESALE NEW ZEALAND LIMITED
2 GUNTON DRIVE
WESTGATE
AUCKLAND 0814
NEW ZEALAND
WWW.COSTCO.CO.NZ

COSTCO WHOLESALE SWEDEN AB
BOX 614
114 11 STOCKHOLM
SWEDEN
WWW.COSTCO.SE/CONTACT

MADE IN CHINA
中國製造



廢電池請回收