

DISTRIBUTED BY :  
COSTCO WHOLESALE CORPORATION  
P.O. BOX 34535  
SEATTLE, WA 98124-1535  
USA  
1-800-774-2678  
WWW.COSTCO.COM

IMPORTED BY / IMPORTÉ PAR :  
COSTCO WHOLESALE CANADA LTD.\*  
415 W. HUNT CLUB ROAD  
OTTAWA, ONTARIO  
K2E 1C5, CANADA  
1-800-463-3783  
WWW.COSTCO.CA  
\* faisant affaire au Québec sous  
le nom les Entrepôts Costco

IMPORTADO POR :  
IMPORTADORA PRIMEX S.A. DE C.V.  
BLVD. MAGNOCENTRO NO. 4  
SAN FERNANDO LA HERRADURA  
HUIXQUILUCAN, ESTADO DE MÉXICO  
C.P. 52765  
RFC: IPR-930907-S70  
(55)-5246-5500  
WWW.COSTCO.COM.MX

IMPORTED BY :  
COSTCO WHOLESALE UK LTD /  
COSTCO ONLINE UK LTD  
HARTSPRING LANE  
WATFORD, HERTS  
WD25 8JS  
UNITED KINGDOM  
01923 213113  
WWW.COSTCO.CO.UK

IMPORTADO POR :  
COSTCO WHOLESALE SPAIN S.L.U.  
POLIGONO EMPRESARIAL LOS GAVILANES  
C/ AGUSTIN DE BETANCOURT, 17  
28906 GETAFE (MADRID) ESPAÑA  
NIF: B86509460  
900 111 155  
WWW.COSTCO.ES

DISTRIBUÉ PAR :  
COSTCO FRANCE  
1 AVENUE DE BRÉHAT  
91140 VILLEBON-SUR-YVETTE  
FRANCE  
01 80 45 01 10  
WWW.COSTCO.FR

DISTRIBUTED BY :  
COSTCO WHOLESALE ICELAND EHF.  
KAUPTUN 3-7, 210 GARDABAER  
ICELAND  
WWW.COSTCO.IS

IMPORTED BY :  
COSTCO WHOLESALE AUSTRALIA PTY LTD  
17-21 PARRAMATTA ROAD  
LIDCOMBE NSW 2141  
AUSTRALIA  
WWW.COSTCO.COM.AU

IMPORTED AND DISTRIBUTED BY :  
COSTCO WHOLESALE KOREA, LTD.  
40, ILJIK-RO  
GWANGMYEONG-SI  
GYEONGGI-DO, 14347, KOREA  
1899-9900  
WWW.COSTCO.CO.KR

IMPORTED BY :  
COSTCO WHOLESALE JAPAN LTD.  
3-1-4 Ikegami-Shincho  
KAWASAKI-KU, KAWASAKI-SHI,  
KANAGAWA 210-0832 JAPAN  
044-281-2600  
WWW.COSTCO.CO.JP

進口商 / 委託製造廠商 :  
好市多股份有限公司  
高雄市中華五路656號  
統一編號 : 96972798  
449-9909 或 02-449- 9909 ( 手機撥打加02 )  
WWW.COSTCO.COM.TW

IMPORTED BY / DISTRIBUTED BY:  
SHANGHAI MINHANG COSTCO TRADING  
CO., LTD  
UNIT 109, NO 388, LIAN YOU ROAD  
MINHANG DISTRICT, SHANGHAI  
CHINA 201107  
+86-21-6257-7065



**3 M/ 10 FT LED SOLAR PATIO UMBRELLA**  
**ITM. / ART. 1900676, 1900691, 1900647, 1900801**

### **ASSEMBLY INSTRUCTIONS**

**IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY  
THIS ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY, NOT FOR  
COMMERCIAL USE.**



**MADE IN CHINA/ 中 國 製 造 / HECHO EN CHINA**

**For customer service in the US and Canada, call: 1-877-730-1583, 9:00AM - 5:00PM EST,  
Monday – Friday, English and French spoken or visit proshade.com.**

澳洲：我們的商品遵照澳洲消費者法（ the Australian Consumer Law ） ， 保證並未設排除條款。您有權因商品重大的缺失要求換貨或退款，以及因可預見的損失及毀損要求合理的賠償金。您也有權在產品無法達到可接受的品質標準以及在該缺失並未造成重大故障時要求提供維修及更換處理。

#### **注意：**

起風或不使用時，遮陽傘應該收起綁緊。  
本產品應遠離火焰及熱源。  
不建議作為營業使用。

#### **保養說明：**

框架：使用溫和無刺激性的洗潔劑及溫水清潔框架。切勿使用具磨蝕性的材料或清潔用品。

遮篷：以溫和無刺激性的肥皂水溶液清洗。徹底地沖洗乾淨並將其展開並懸掛滴乾。

#### **重要資訊：**

運送途中傘骨可能受到擠壓。打開遮陽傘前請詳閱說明，以避免造成永久性的傷害。

遮陽傘作為戶外使用；AC配接器可適用於室內及戶外。

### 3公尺 / 10呎戶外LED遮陽傘

#### 保固書

品項 / 商品編號 1900676, 1900691, 1900647, 1900801

請注意，製造商為3公尺 / 10呎戶外LED遮陽傘，提供原始材料與做工一年零瑕疵保固。

#### 框架

框架的材料與做工保證一年零瑕疵保固。因不當安裝或暴露於水和 / 或冰點以下的溫度而造成的損壞不在保固範圍內。框架內請勿積水。

#### 表面塗層

產品在未經刮傷或磨損的狀況下，提供一年表面塗層不會脫落、裂開或起泡之保固服務。不正常磨損與裂縫造成的刮傷與斑駁，不在保固範圍內。暴露於惡劣氣候而造成褪色並不在保固範圍內。

#### 布料

布料提供一年不脫線之保固。因暴露於惡劣氣候、化學品或噴濺造成的褪色不在保固範圍。

注意：所有的使用操作應遵照說明書指示。


\* 本保固不包含以下事項：

不當使用或濫用所造成的損壞；疏忽或不當照顧所造成的損壞；天災（包括但不限於強風、颶風、龍捲風與暴風）均不在本保固範圍內。保固自產品購買日起一年後自動失效。

When opening the package, please carefully check and confirm if all accessories are in the package. If any part is missing or damaged, do not attempt to assemble or return the umbrella. Contact our customer service toll free at **1-877-730-1583** for replacement parts or help.

Estimated Assembly Time: 10 minutes

No tools required for assembly.



No.	DESCRIPTION	QTY
A	Solar panel	1 PC
B	Finial with cap, battery included	1 PC
C	Upper frame with canopy	1 PC
D	Bottom pole	1 PC
E	AC Adapter	1 PC


#### NOTE:

The Finial (B) contains two lithium batteries (2 x 2200mAh). Do not attempt to open the Finial (B) when in use. Do not use the Umbrella without the Finial (B) properly installed. If batteries are not working properly, please contact customer service to replace the entire finial. Do not attempt to replace the batteries.

#### AC Adapter:


Input: 100V~240V AC, Output: 4.2V DC. AC adapter can be used for both indoor and outdoor. UL Certification number is: E486164.

**Step 1:** Remove the cap on the finial (B) and connect with the solar panel (A), then attach them to umbrella. Keep the cap for future use.



**Step 3:** Have the umbrella securely fastened into an umbrella base (not included).


**Step 2:** Insert the bottom pole into the upper pole housing and lock into place.



The batteries will be fully charged after 8 hours of sunlight or 5-6 hours using the AC adapter.

**MAKE SURE THE LED LIGHTS ARE OFF FOR THE SOLAR PANEL TO RECHARGE THE BATTERY.**


**CAUTION:** YOU MUST CHARGE BATTERY BEFORE FIRST USE. Please note that battery can discharge if it is left unused or uncharged for a long period of time. Failure to charge the battery will result in premature dimming of the lights on your solar umbrella.




**步驟7：**  
關閉開關。將曲柄以逆時針方向轉動直到遮陽傘完全收起。以束線帶將遮篷綁好。

**注意事項：**

- 傘頂蓋 (B) 內建兩個鋰電池 (2 x 2200mAh)。電池以太陽能板進行充電時，應在白天將開關壓至關閉位置。充電時間須視陽光強弱而定；然而，建議至少充電8小時。
- 電池以AC配接器進行充電時，將充電埠的蓋子拆下，與AC配接器的尾端相接，接著再將兩端固定在一起。充電時間約為5~6小時。
- AC配接器室內與戶外皆適用，然而使用戶外插頭時應加以遮蓋，以防止使用時有水濺入。
- 若遮陽傘收納在箱子內，應將太陽能板及傘頂蓋拆下以防受損。
- 本裝置符合美國聯邦通訊委員會 (FCC) 規範的15部分之規定。操作時需遵守以下兩項條件限制：(1) 本裝置不致造成有害的干擾，(2) 本裝置必須能承受所接收之任何干擾，包括可能造成非預期的操作干擾。







#### 步驟4：


打開遮陽傘前，將傘骨稍微拉開並讓它自然的張開。

將曲柄以順時針方向轉動直到連結槽觸及止動環為止。

此時，遮陽傘應已完全展開並可加以使用。

日常的一般使用，可在夜間想要使用太陽能燈時開啟燈具開關，

而在使用後關閉開關即可。




#### Step 4:

Before opening your umbrella, gently pull apart and separate the ribs into their natural, open position.

Turn the crank handle clockwise and continue to turn until the hub has reached the stop ring. At that time, the umbrella is fully open and ready to use.

For everyday, normal use, turn the light switch on at night when you want to use the solar light and turn the light switch off after use.




#### 步驟5：

遮陽傘完全展開後，持續轉動曲柄可使遮陽傘傾斜。

#### 步驟6：

將軸環下拉並轉動，可以輕易地360度轉動遮陽傘。轉動到自己想要擺設的位置後，即可鬆開軸環，而遮陽傘便能牢牢地固定就位。

**注意：** 確認遮陽傘完全地傾斜。若只是在半傾斜的位置，只要風吹就可能將遮陽傘吹回直立的狀態。




#### Step 5:

Keep turning the crank to tilt the umbrella after the umbrella is fully opened.

#### Step 6:

Pull down and turn the collar in order to easily rotate the umbrella 360 degrees. Stop at the desired position, release collar, and the umbrella firmly locks in place.

**Caution:** Make sure the umbrella is fully tilted. If left in a half-tilted position, any wind will bring the umbrella back to upright position.




#### Step 7:


Turn off the switch, turn the crank handle counterclockwise until umbrella is fully closed. Use tie straps to secure umbrella canopy.

#### NOTE:

- The Finial (B) contains two lithium batteries (2 x 2200mAh). To charge the batteries using the solar panel, press the switch to the off position during daylight. Charging time depends on the amount of sunlight; however, at least 8 hours is recommended.
- To charge batteries with the AC adapter, remove the cap on the charging port, connect with the end of AC adapter and then screw together. Charging time is approximately 5~6 hours.
- The AC adapter could be used both indoor and outdoor, while the outdoor plug needs to be covered to prevent water entering when it is in use.
- If the umbrella is stored in a box, the solar panel and finial must be removed to avoid damage.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, (2) this device must accept any interference received, including interference that may cause undesired operation.




**步驟1：** 取下傘頂蓋 (B)，並裝上太陽能板 (A)。接著把裝配件和遮陽傘安裝固定。須保留上蓋，待稍候使用。



**步驟3：** 將遮陽傘確實地固定在陽傘底座 (產品未附)。

**步驟2：** 將下端傘架裝入上端豎架並固定就位。



在陽光下進行8小時的充電，或是以AC配接器充電5-6小時可將電池充飽。


**確認LED燈已關閉，以便太陽能板進行電池的充電作業。**

**注意：** 必須在首次使用之前為電池充電。  
請注意，電池在未使用或長時間未充電時會放電。  
未使電池充電會造成遮陽傘的燈光提早變暗。

打開包裝時，請仔細地檢查並確認全的數配件是否已在包裝內。若有任何零件遺漏或受損，請勿試圖組裝遮陽傘或將其退回。請與我們的客服聯絡，來電請撥**1-877-730-1583**，可要求更換零件或尋求相關協助。

預計組裝時間：10分鐘

組裝時無需使用工具。



編號	內容說明	數量
A	太陽能板	1
B	傘頂蓋，內裝電池	1
C	上端框架與遮篷	1
D	下端傘架	1
E	AC配接器	1

**注意事項：**

傘頂蓋 ( B ) 內建兩個鋰電池 ( 2 x 2200mAh )。請勿在使用時試圖打開傘頂蓋 ( B )。請勿在未將傘頂蓋 ( B ) 確實地安裝好時使用遮陽傘。若電池未能正常使用，請與客服聯絡以便更換整組傘頂蓋。請勿嘗試更換電池。

**AC配接器：**

輸入：100V-240V AC、輸出：4.2V DC。AC配接器適用於室內及戶外。  
UL認證編號：E486164。

**3M / 10 FT LED SOLAR PATIO UMBRELLA  
LETTER OF WARRANTY**

**ITM. / ART. 1900676, 1900691, 1900647, 1900801**

Please be advised that the manufacturer provides a one-year warranty, that the 3 m / 10 ft LED Solar Patio Umbrella will be free from defects in the original materials and workmanship.

**Frames**

Frames are warranted to be free from defects in materials and workmanship for a period of one year. Damage to frames or welds due to improper assembly or exposure to water and sub-freezing temperatures is not covered. Do not allow water to accumulate inside frames.

**Finish**

The finish is warranted against peeling, cracking, or blistering for a period of one year, provided the unit has not been scratched or abraded. Scratches and chips resulting from abnormal wear and tear are not covered. Fading resulting from exposure to elements is not covered.

**Fabric**

Fabric is warranted for a period of one year against separation at the seams. Fading or discoloration resulting from exposure to the elements, chemicals, or from spills is not covered.

Note: All operation should be according to instruction manual.

\*This warranty DOES NOT COVER the following items:

Failure caused by unreasonable or abusive use, failure caused by neglect of reasonable and necessary care, acts of nature (including but not limited to wind, hurricanes, tornadoes, and storms) are not covered by this warranty. **The product is not covered by this warranty after one year from the date of purchase.**

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### CAUTION:

The umbrella should be lowered and secured in windy conditions or when not in use.  
Keep all flame and heat sources away from this umbrella.  
Not recommended for Commercial use.

### CARE INSTRUCTION:

FRAME: To clean, use a mild detergent and warm water on the frame. Do not use abrasive materials or cleaners.

CANOPY: Wash with a mild solution of soap and water. Rinse thoroughly and drip-dry in an open position.

### IMPORTANT INFORMATION:

Umbrella ribs may compress during shipping. Please read these instructions before opening your umbrella to avoid causing permanent damage.



3公尺 / 10呎戶外LED遮陽傘

品項 / 商品編號1900676, 1900691, 1900647, 1900801

安裝說明

內含重要說明，請妥善保存以供日後參考：請詳閱  
本產品僅供居家戶外使用，不得作為營業用。



美、加地區若需客戶服務，請洽: 1-877-730-1583, 來電請於美東標準時間，  
禮拜一至禮拜五的上午9:00 - 下午5:00，  
我們提供英語及法語服務，或可連線至proshade.com。